



- Current day
- Zone selectors
- Current time
- Time set
- Holiday set
- Screen clean
- Power

## Product overview

The Ambiente TM4-TS four channel programmer with four on/off times per channel with five/seven day operation. The programmer is designed to link with a UH3 wiring centre but can equally be used to replace standard programmers. Programmers are often difficult to understand but the touch screen feature makes this unit very simple to use.

### Normal Run Mode

In normal run mode, the time clock will display the current time. It can also be set to show the status for a particular zone. To display the status of a zone, press Zone 1 – Zone 4. This screen will be displayed until you press Done and return to the main menu. The time clock has a 24 hour clock.

### Programming a Holiday

The time clock can be programmed to switch all zones off for a set number of days - ideal for when you are going away.

### Selecting 5/2 Day or 7 Day Programming

Each zone can be programmed to work in 5/2 (Weekday/Weekend) or 7 Day mode.

### Adjusting the Switching Times

Each zone has 4 On/Off times.

### Copy Function

The Time clock has a copy function, enabling you to copy switching times from one zone to another.

### Mode Select

Each zone can operate in 3 modes:

Auto: The zone will work to the programmed switching times.

Off: The zone will switch off completely.

Constant: The zone will stay on indefinitely.

It is recommended that a 45mm back box is used with this unit to allow space for cables to all four channels.

## Wiring diagram

